

DIY electrophysiology

(The safest thing you can do involving connecting your cranium to an electronic device you built in your garage.)

Flavours

- Electrocardiography (ECG) - heart.
- Electroencephalography (EEG) - brain.
- Electromyography (EMG) - muscle.
- Electrocorticography (ECoG) - cortical surface (don't try this one at home).

Practical applications and other applications

Practical

- Sleep tracking.
- Brain-computer interfaces.
- Biofeedback.
- Cardiac abnormality identification.
- Seizure detection.

Practical applications and other applications

Practical

- Sleep tracking.
- Brain-computer interfaces.
- Biofeedback.
- Cardiac abnormality identification.
- Seizure detection.

Questionably-practical

- Binaural beats.
- Game design.

Practical applications and other applications

Practical

- Sleep tracking.
- Brain-computer interfaces.
- Biofeedback.
- Cardiac abnormality identification.
- Seizure detection.

Questionably-practical

- Binaural beats.
- Game design.

Awesome

- Object recognition with evoked-response potentials.
- Controlling your powered exoskeleton.

- Electrodes (wet/dry, active/passive).
- Instrumentation amplifier.
- Bandpass filter (for EEG, high-pass at $\sim 1\text{Hz}$, low-pass at $\sim 40\text{Hz}$).
- Notch filters at 50Hz (for Australian AC).
- Driven right-leg circuit.
- ADC.

Proprietary consumer hardware

- NeuroSky.
- Emotiv (EPOC, Insight).
- BCInet (formerly Neural Impulse Actuator).
- Star Wars Force Trainer.

Open hardware designs

OpenBCI EEG board




Figure 1 <http://openbci.com>

Open hardware designs

Olimex ECG Arduino shield




Figure 2 <https://www.olimex.com/>

Analysis: know your squiggly lines




Figure 3: OpenBCI Processing GUI (image by Conor Russomanno)

Analysis: Fourier transform

- Breaks a signal into its components (sinusoids).
- Allows identification of EEG bands (“brainwaves”).

EEG bands

Frequency (Hz)	Band	Significance
0-4	delta	slow-wave sleep (stage-3 NREM)
7.5-12.5	alpha	thalamic pacemaker, associated with relaxed states
12.5-30	beta	reduced in sleep and coma, signifies normal wakefulness
25-100	gamma	hippies talking about consciousness

Analysis: wavelet decomposition

- Breaks a signal into individual 'spikes' over time.
- Allows identification of common features, and provides a basis for isolating uncommon features.

Analysis: wavelet decomposition

- Breaks a signal into individual 'spikes' over time.
- Allows identification of common features, and provides a basis for isolating uncommon features.

Uncommon features: seizure onset




Figure 4: Partial temporal-lobe seizure (image: Teddy Poh)

Toolkits

- EEGLAB - <http://sccn.ucsd.edu/eeglab/>.
- OpenVIBE - <http://openvibe.inria.fr>.
- SciPy - <http://www.scipy.org/>.

Training datasets

- PhysioBank - <http://physionet.org/physiobank/>.

- OpenBCI: <https://github.com/openbci>
- OpenVIBE: <http://openvibe.inria.fr>
- Arduino ECG: <https://github.com/fractalcat/arduecg>

Slides

<https://tesseract.org/doc/slides/>

Contact

Sharif Olorin (sio@tesseract.org) - contrary to rumor, neither citizen nor scientist.